



4900 hand drawn recessed track_

for light and medium weight curtains



STANSONS_

4900

hand drawn track

The Stansons 4900 track is a built-in profile. It has to be mounted in a channel cut into a wooden mounting surface. The tapering sides of the track give it an elegant look. An attractive, sleek track that can be used in your home.

- The ideal track for sheers and lightweight or medium-heavy curtains.
- Easy to bend and exceptional quality.
- Can be forward or reverse bent in different radii.
- Concealed mounting with Torx screws
- Silent and smooth running, also round bends.



standard colours

Natural anodised



RAL 9010 white




features

MATERIAL:	ALUMINIUM
COLOUR:	WHITE NATURAL ANODISED,
DIMENSIONS:	17 X 17 MM
WEIGHT PROFILE:	97 GR/MI
MOUNTING:	CEILING

High quality, wear-resistant coating, highly colourfast, UV-resistant. Other RAL colours & special coatings on request.

profile specifications

Aluminium profile:



Colours with RAL code and lengths (m)
4900:

	RAL	4	5	6	7
white	9010			•	
natural				•	

4900 with punch type 'G':

	RAL	4	5	6	7
white	9010			•	
natural				•	

Mounting surface:

- wood

Bracket type:

- ceiling bracket


Bendings:

bending radius	bending tool
R 10 cm	1012
R 10 cm	1015
R > 80 cm	1018

R 10 cm


R > 80 cm

mounting




Correct: Correctly mounted track with important dimensions.

Mounting advice: if you want to create a curve, bend the track first and then cut the channel.




Incorrect: Make sure the channel edges are straight to prevent deformation of the running face of the track.




Incorrect: Make sure the channel is cut to precisely 6 mm deep is to prevent deformation of the running face of the track.


filler position for bending:



punch holes:




mounting guideline



The distance between the brackets can vary depending on the following factors: the mounting surface (wood, concrete or plaster), the weight of the curtains and the curtain fabric production method, the specific application and the system usage intensity. General advice: with the curtains open, place additional brackets where the pleats bunch together. Also place additional brackets before and after bends.

application example



Manual insertion of a spring stop 4003 in a pre-punched hole. The last glider 6009 is placed in an end stop so that it is secured in position between the 4003 and the end of the channel or against the wall.

specification guide

Material:

- Aluminium EN AW-6060-T66.
- Anodised in accordance with the Qualanod standard.
- Powder coated in accordance with the Qualicoat standard..

Additional mounting options

Standard punched hole:
Ø 2.5 mm, every 15 cm

